

INSTRUCTIONS

ATHENA BOLLARD

4640.52

Please read the instructions before commencing installation
And retain for future reference.

SPECIFICATIONS:

- **Fitting:** Aluminum body with PC.
- **Lamp types:** E27 23W.
- **Protection against electric shock:** CLASS I requires earth connection.
- **Ingress Protection:** IP44. Protection against dust and water
- **Ballast:** Without LED Driver
- **Quality/Corrosive Rating:** Suitable for garden use, commercial use and indoor/outdoor applications
- **Ambient temperature range:** -20° to +40°

INSTALLATION INSTRUCTIONS:

⚠ Electrical products can cause death, injury or damage to property. Installation of this product must be carried out by a qualified electrician, in accordance with SANS 10142. On completion of installation, ensure that the Certificate of Compliance is updated.



CAUTION: Risk of electric shock

PLEASE NOTE: The light source contained on this luminaire shall only be replaced by the manufacturer or the service agent or a similar qualified person.


Ensure mains supply is switched off.

- **Fig 1.** Screw out the three screws on the base
Make 3 point according lamp base.
Use a gun drill 3 holes.
Putting plastic expansion to hole.
- **Fig 2.** Tighten the screws
Open lamp plastic head
Install bulb
Connecting the Terminal Block
- **Fig 3.** Put plastic head in the lamp and tighten the screws
Three screws fill into ground

Switch on mains supply and test the fitting.

WARNING:

- Ensure all items and screws are secure and fitted correctly.



Spazio Lighting (Pty) LTD

JOHANNESBURG OFFICE: 52 Andries Street North | Wynberg/Sandton | South Africa | Tel: +27 11 555 5555

CAPETOWN OFFICE: 36 Milner Road, Paarden Eiland | 8001 | Tel: +27 21 461 0061

info@spazio.co.za