

INSTRUCTIONS

MOORE WALL

5276

Please read the instructions before commencing installation and retain for future reference.

SPECIFICATIONS:

- **Fitting:** Body made in stainless steel with opal glass diffuser.
- **Lamp types:** 6W / 230V / LED 3000K
- **Protection against electric shock:** CLASS I. Requires earth connection.
- **Ingress Protection:** IP44. Protection against the entry of solid bodies greater than 1mm, Protection against water sprays.
- **Ballast:** Includes integral LED driver.
- **Quality/Corrosive rating:** Suitable for indoor applications.
- **Ambient temperature range:** -8°C to +55°C.

INSTALLATION INSTRUCTIONS:

⚠ Electrical products can cause death, injury, damage to property. Installation of this product must be carried out by a qualified electrician, in accordance with SANS 10142. On completion of installation, ensure that the Certificate of Compliance is updated.



CAUTION: Risk of electric shock

PLEASE NOTE: The light source contained on this luminaire shall only be replaced by the manufacturer or the service agent or a similar qualified person.

Switch off mains supply.

- Remove the mounting bracket and fix it to the wall. (Fig. 1)
- Connect the fitting to its electrical source using the terminal block provided. (Fig. 2)
Brown (Live) - to Brown or Red
Blue (Neutral) - to Blue or Black
Green/Yellow (Earth) - to Green/Yellow or Copper.
- Fix the base to the wall bracket. (Fig. 3)
- Attach the glass shade. (Fig. 4)

Switch on mains supply.

WARNING:

Ensure all items and screws are secure and fitted correctly.



MOORE WALL

Fig.1




Fig.2




Fig.3




Fig.4

